
BUNN®

3.0 Gallon TITAN TF SERVER



USE & CARE INFORMATION

CAUTION: CLEAN AND SANITIZE YOUR SERVER BEFORE USING. SEE NOTE 1 of DAILY CLEANING.

BUNN-O-MATIC CORPORATION

POST OFFICE BOX 3227 SPRINGFIELD, ILLINOIS 62708-3227 PHONE: (217) 529-6601 FAX: (217) 529-6644



INTRODUCTION

This server is intended for use with a BUNN® TITAN DUAL, or TITAN SINGLE coffee brewer only. When proper precautions are followed, 1.5 to 3.0 gallons of coffee may be brewed directly into the server and then transported to a remote serving location. The server must be placed on a sturdy counter or shelf.

USER NOTICES

The notices on this server should be kept in good condition. Replace unreadable or damaged labels.

#26186.0000




DAILY CLEANING

CAUTION: CLEAN AND SANITIZE YOUR SERVER **DAILY**

NOTE: Bunn-O-Matic recommends the 3 step method for cleaning and sanitizing the server. The 3 step method consists of hot soapy water using an approved detergent, a fresh water rinse, and an aqueous sanitizing solution using an approved **non-chlorine** sanitizer. **Do not submerge server.**

- 1. Run a complete brew cycle *of just hot water* into the server and let it set for a minute. Empty the server completely by opening the faucet.
- 2. Remove the lid, fill server with cleaning solution and thoroughly clean the inside of server.
- 3. Rinse server thoroughly using fresh water rinse.
- 4. Fully fill server with sanitizing solution for 5 minutes then drain through fully open faucet.
- 5. Remove the faucet handle/stem assembly by unscrewing the faucet nut just behind the faucet handle.
- 6. Use enclosed cleaning brush to thoroughly clean the faucet spout and connector.
- 7. Remove the cap, sight gauge tube and washers.
- 8. Use enclosed cleaning brush to thoroughly clean the fill tube of the lid assembly and sight gauge tube.
- 9. Disassemble the faucet/stem assembly. Thoroughly wash all faucet parts and lid in a mild detergent and water solution. Rinse the parts in hot water. Sanitize the parts for five minutes, then air dry completely.
- 10. Reassemble the faucet/stem assembly and attach it to the faucet.
- 11. Install the sight gauge tube and washers in the shroud and secure with the shroud cap.
- 12. Wash the entire outside surface of the server with a clean damp cloth.

2 40359 082807



17. 40106.0000

1.	39542.1000	Shroud, Sight Gauge (Includes Item 4)	18.	26186.0000
2.	35010.0000	Plate, Decal Mounting	19.	40097.0001
3.	35009.0000	Decal, Bunn	20.	32591.1000
	35009.0001	Decal, Plain Black	21.	12422.0001
4.	35004.0002	Backing, Sight Gauge 3.0 Gal.	22.	39543.0001
5.	35005.0003	Sight Gauge Tube 3.0 Gal.	23	12422.0012
6.	39083.0000	Cap, Shroud	24.	40271.1100
7.	02367.0000	Screw, Truss Head #6-32 x .62"		45279.0000
8.	39143.0001	Washer, Sight Gauge Tube	25.	01221.0000
9.	39081.0000	Handle, Faucet, Bunn (Horizontal Faucet)	26.	03093.0002
10.	35003.0000	Nut, Faucet Spout (Horizontal Faucet)	27.	26685.0000
11.	00601.0000*	Faucet Spring		26685.0003
	29164.0000*	Faucet Stem	28	26684.0000*
13.	00600.0000*	Faucet Seat Cup		07096.0007*
	35074.0000	Screw, Hex Hd Black M4 x .7x25		29165.0001*
15.	40132.0000	Spout, Faucet (Horizontal Faucet)	30.	*
	41159.0001	Shank, Faucet (Vertical Faucet)	31.	35301.0000
16.	39487.1000	Lid Assembly 3.0 Gal. (Includes item 17)		

Cap Assembly

	13 12	11 10
18.	26186.0000	Decal, Warning Hot Liquid
19.	40097.0001	Spacer
20.	32591.1000	Tube, Silicone .50" I.D. x 2.0"(Cut to length)
21.	12422.0001	Clamp, Tube .59"/.66" I.D.
22.	39543.0001	Guard, Faucet
23	12422.0012	Clamp, Tube .81"/.97" I.D.
24.	40271.1100	Cover, Bottom
	45279.0000	Screw, Pan Head #8-32 x .25"
25.	01221.0000	C-Ring, Faucet Shank
26.	03093.0002	Wing Nut, Faucet
27.	26685.0000	Faucet Assy, Bunn Handle
	26685.0003	Faucet Assy, Plain Black Handle
28	26684.0000*	Faucet Handle, Bunn
	07096.0007*	Faucet Handle, Plain black
29.	29165.0001*	Faucet Bonnet
30.	*	Faucet Body (Not available. Order item 27)
31.	35301.0000	Brush, Cleaning (Not Illustrated)

^{*} Component of item 27

BUNN-O-MATIC COMMERCIAL PRODUCT WARRANTY

Bunn-O-Matic Corp. ("BUNN") warrants equipment manufactured by it as follows:

- 1) All equipment other than as specified below: 2 years parts and 1 year labor.
- 2) Electronic circuit and/or control boards: parts and labor for 3 years.
- 3) Compressors on refrigeration equipment: 5 years parts and 1 year labor.
- 4) Grinding burrs on coffee grinding equipment to grind coffee to meet original factory screen sieve analysis: parts and labor for 3 years or 30,000 pounds of coffee, whichever comes first.

These warranty periods run from the date of installation BUNN warrants that the equipment manufactured by it will be commercially free of defects in material and workmanship existing at the time of manufacture and appearing within the applicable warranty period. This warranty does not apply to any equipment, component or part that was not manufactured by BUNN or that, in BUNN's judgment, has been affected by misuse, neglect, alteration, improper installation or operation, improper maintenance or repair, damage or casualty. This warranty is conditioned on the Buyer 1) giving BUNN prompt notice of any claim to be made under this warranty by telephone at (217) 529-6601 or by writing to Post Office Box 3227, Springfield, Illinois 62708-3227; 2) if requested by BUNN, shipping the defective equipment prepaid to an authorized BUNN service location; and 3) receiving prior authorization from BUNN that the defective equipment is under warranty.

THE FOREGOING WARRANTY IS EXCLUSIVE AND IS IN LIEU OF ANY OTHER WARRANTY, WRITTEN OR ORAL, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OF EITHER MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. The agents, dealers or employees of BUNN are not authorized to make modifications to this warranty or to make additional warranties that are binding on BUNN. Accordingly, statements by such individuals, whether oral or written, do not constitute warranties and should not be relied upon.

If BUNN determines in its sole discretion that the equipment does not conform to the warranty, BUNN, at its exclusive option while the equipment is under warranty, shall either 1) provide at no charge replacement parts and/or labor (during the applicable parts and labor warranty periods specified above) to repair the defective components, provided that this repair is done by a BUNN Authorized Service Representative; or 2) shall replace the equipment or refund the purchase price for the equipment.

THE BUYER'S REMEDY AGAINST BUNN FOR THE BREACH OF ANY OBLIGATION ARISING OUT OF THE SALE OF THIS EQUIPMENT, WHETHER DERIVED FROM WARRANTY OR OTHERWISE, SHALL BE LIMITED, AT BUNN'S SOLE OPTION AS SPECIFIED HEREIN, TO REPAIR, REPLACEMENT OR REFUND.

In no event shall BUNN be liable for any other damage or loss, including, but not limited to, lost profits, lost sales, loss of use of equipment, claims of Buyer's customers, cost of capital, cost of down time, cost of substitute equipment, facilities or services, or any other special, incidental or consequential damages.

392, AutoPOD, AXIOM, BrewLOGIC, BrewMETER, Brew Better Not Bitter, BrewWISE, BrewWIZARD, BUNN Espress, BUNN Family Gourmet, BUNN Gourmet, BUNN Pour-O-Matic, BUNN, BUNN with the stylized red line, BUNNlink, Bunn-OMatic, Bunn-O-Matic, Bunn-O-Matic BrewWIZARD, Bunn-O-Matic BrewWIZARD, Bunn-O-Matic BrewWIZARD, Bunn-O-Matic BrewWIZARD, Bunn-O-Matic BrewWIZARD, Bunn-O-Matic Corporation.

4 40359 092611